

# APPAIRAGE DE VOTRE SOURCE BLUETOOTH PAIRING YOUR BLUETOOTH DEVICE



## SUIVEZ IMPÉRATIVEMENT CES 3 ÉTAPES POUR RÉGLER VOTRE SYSTÈME

- 1 - Connecter le WTX-500 sur une entrée auxiliaire de votre amplificateur HiFi comme indiqué sur la photo. Branché l'adaptateur secteur. La led bleu doit clignoter.
  - 2 - Allez dans le menu réglage, sous-menu bluetooth, de la source audio que vous souhaitez appairer avec votre WTX-500. Après quelques instants, le WTX-500 apparaîtra sous le nom ADVANCE ACOUSTIC. Sélectionnez le et validez sa connexion. Aucun code Pin n'est nécessaire. Lorsque l'appairage est réalisé, la led bleu devient fixe.
  - 3 - Passer votre périphérique audio en mode lecture et profitez d'une restitution sonore de qualité "Airblue Certified" grâce à la technologie Apt-X Bluetooth.
- Si vous vous éloignez votre périphérique audio à une distance hors de portée de votre système Air, la liaison bluetooth se désactivera et vous devrez répéter l'étape 2 pour vous reconnecter. Si vous souhaitez changer de périphérique Bluetooth, vous devez désactiver la connexion du premier et activer la connexion du second via les menus réglages respectifs.

## TO FINE TUNE YOUR SYSTEM, FOLLOW THOSE 3 STEPS

- 1 - Connect the WTX-500 on an auxiliary input of your HiFi amplifier or AV receiver. Plug on an outlet the power supply adapter. The blue led of your WTX-500 is flashing.
  - 2 - Go to the Bluetooth Manager of your iPhone, iPod touch, iPad, tablet, smartphone, PC or MAC computer, then go on the bluetooth settings. You will see a new bluetooth connection under ADVANCE ACOUSTIC name. Confirm that you choose it, after few seconds, your audio device is pairing with the WTX-500. If pairing is ok, then, the blue led of the Air amplifier will be fixed. You don't need any Pin code confirmation.
- Your WTX-500 is now connected and ready to play music! Just play music on your device as you normally would and the sound will come out of your HiFi system.
- If you move out of range or turn off the Bluetooth feature on your audio device, the Bluetooth Music Receiver will disconnect from your device.
- To reconnect, simply access the Bluetooth Manager on your device and select the ADVANCE ACOUSTIC connection.